Tech Note — T-Nut Pattern – 7700 Headrest Hardware

Freedom Designs, Incorporated
7801 S. Jackson Rd., Pharr, Texas 78577
phone: 800-331-8551 fax: 888-582-1509
e: customerservice@freedomdesigns.com
www.freedomdesigns.com

Item(s) affected:
Reference patern for all FDI solid back inserts and headrest pads when 7700 headrest hardware is used.

